


# MILTON SIGNAL BELL / CHIME - INFORMATION SHEET

BELL OR CHIME MUST BE INSTALLED UPRIGHT.  
USE ALL MOUNTING HOLES TO FASTEN.



**MODELS 825, 827, 830 - SEE OTHER SIDE.**

## LIMITED WARRANTY

ALL MILTON PRODUCTS are manufactured to exacting standards, using the finest materials and are GUARANTEED AGAINST ALL DEFECTS IN MATERIALS AND/OR WORKMANSHIP for a period of one year after date of purchase. WITH PROPER CARE, THEY WILL PROVIDE LONG AND "TROUBLE-FREE" SERVICE.


If a user feels any Milton Product, which has not been abused or misused, has not given reasonable service, he (the user) may return that product, prepaid, to the factory. (UPS or Parcel Post Only).

Any product, which factory inspection reveals to be defective in materials and/or workmanship within the terms of our Limited Warranty, will be repaired or replaced, no charge, at our option. Repairable products, which inspection reveals to be abused, misused, or worn in service, and which are not considered expendable, will be reconditioned for a nominal service charge, and returned to the user.

THE MILTON NO. 825 REMOTE CONTROL AIR SWITCH IS AN AIR OPERATED *MOMENTARY CONTACT* ELECTRICAL CONTROLLER. IT WILL OPERATE ALL MILTON REMOTE CONTROLLED SIGNALS (MODELS 827 AND 830) AS WELL AS BELLS, BUZZERS, LIGHTS, ETC. IT WILL ALSO OPERATE RELAYS FOR INDUSTRIAL APPLICATIONS.

#### ELECTRICAL RATING

0 - 240 VOLTS AC OR DC, 10 AMPS



This is a pictorial wiring diagram to suggest various hook-up options and to show a typical circuit path. Any installation must be properly terminated and insulated and must conform to all applicable codes. Consult a qualified electrician.

NOTE: The center terminal on the terminal strip can be used as a convenient tie point if desired.

**IMPORTANT:** The model 825 must always be mounted with the hose connector tube pointing straight down. Remove plastic cap before attaching hose.

